



NOTE: ALL FASTENERS SHALL BE LOCATED IN THE SEAM AREA. FASTENERS NOT LOCATED IN THE SEAM AREAS SHALL BE DRIVEN THROUGH OR COVERED WITH CURETITE

DRAIN BOARD (BY OTHERS)
3" OVERLAP (TYP.)

TIE-BACK BRACKET TO BE FILLED WITH BENTONITE MASTIC AND COVERED WITH TEGRATITE SHEET

OVERLAP SEAMS 3" MIN. AND SECURED WITH WIDE CROWN BOX STAPLES OR NAILS WITH WASHERS LOCATED 30" O.C.

STEEL PILE (I-BEAM)

PLACE CEMENT BOARD OVER THE SOLDIER PILES AT THE AREA TO BE CUT (OPTIONAL)

LAGGING

ALL VOIDS GREATER THAN 1" IN WIDTH OR 1/2" IN HEIGHT OR DEPTH SHALL BE REPAIRED WITH A MINIMUM 24 GAUGE SHEET METAL OR TREATED PLYWOOD

TEGRASEAL WATERSTOP AT ALL COLD JOINTS

TEGRATITE PLUS STARTER STRIP TO EXTEND 12" MIN. BELOW TOP OF FOOTING / MAT SLAB



Tel: 952-888-1816
Web: www.tegraseal.com

LAGGING WALL

Designed	JF	2023
Drawn	TB	2023
Approved	JF	2023
FILE NAME: 0202-140		
SCALE: N.T.S.		

This document, including any drawings, specifications, and calculations herein, contains information that is proprietary to Tegraseal. This document and the information contained herein is confidential, and may not be reproduced or disclosed without the prior written consent of Tegraseal. Further, the use of this document or any information presented herein is restricted to the specific project and purpose for which it was prepared. Any other use is strictly prohibited. Tegraseal DISCLAIMS ANY LIABILITY for any unauthorized, unintended or other impermissible use of this document or any information it contains.